


eGlide Steal - EGS001G
Quick Start Guide

Charging


Fully charge your device for 6 hours before the first use.




The battery indicator will show that your device is charging.



Screen Basics




Connecting to Wi-Fi




Enter the settings app located in the apps menu and choose Wi-Fi.

Installing Apps



Enter the Ematic App Shop and tap an app to download.
(First time sign-up is required.)




When the installation is complete you will be prompted to open the app, or you can locate the app in the apps menu.


Reset/Restore/User Manual

Reset Device

The reset button is located on the side of the unit. Reset the device by pressing the button with a small object such as a paper clip.



Factory Restore
Select Backup & reset in the settings app to restore factory settings. This will erase all data on the tablet.





Full User Manual
Use the File Manager app to locate the Manual folder.



FileManager

Connecting to a Computer




Connect to your computer by USB.
The USB connection is located next to the DC port.


Turn on USB Storage.

Tap OK to allow USB Storage.


PC



Choose open folder to view files or select the removable disk.




You will now be able to drag and drop files from your computer on to your tablet just as you would with a USB flash drive.




Right click on the file to copy, delete or view the file properties.


Mac



Use finder to go to Devices and choose EGS001G.



You will now be able to drag and drop files from your computer on to your tablet just as you would with a USB flash drive.



Control click on the file to compress, copy, move to trash or get info.
Control click on the device to eject.

Customer Support

Visit ematic.zendesk.com to stay updated with announcements, get answers from the community, and share your feature suggestions with us.

- [Tips & Tricks](#)
- [FAQs](#)
- [Community Help](#)

You can also submit a request for assistance or send us an email to customerservice@ematic.us.

The screenshot shows the eMatic Customer Support homepage. It features a header with the eMatic logo and "Customer Support". Below the header are navigation links for "HOME", "KNOWLEDGE BASE", "SUBMIT A REQUEST", and "CHECK YOUR EXISTING REQUESTS". The main content area has a heading "Welcome to eMatic Customer Support" with a sub-note about staying updated with announcements. It includes sections for "Knowledge Base", "Announcements (0)», "Community Help (30)», "Tips & Tricks (4)», and "Feature Requests (1)». Each section lists various topics or requests.

©2012 Ematic. Windows™ is a registered trademark of Microsoft Corp. in the United States and other countries; Mac OS® is a registered trademark of Apple Inc.; Linux™ is a registered trademark of Linus Torvalds. Android is a trademark of Google Inc. The Android Robot logo is a trademark of Google Inc and used under a Creative Commons Attribution license. Ematic is not affiliated with Google Inc. Zoodles is a trademark of Inquisitive Minds, Inc and used by Ematic under a license. Ematic is not affiliated with Microsoft, Apple, Inc., Linux, or Google, Inc., (including Android).